

Using KEP add on drivers with EasyBuilderPro Setup Software

EasyBuilderPro supports add on drivers. These are drivers developed by KEP for special applications and extended support over and above the list of Standard PLC drivers in the software.

Steps to Activate a Driver

1. Copy the **devicetype.def** file into the EasyBuilderPro main directory (C:\Program Files (x86)\EBPro), replacing the existing file.
2. Find the sub-directory under the EasyBuilderPro main directory named **driver**.
3. Copy the driver files into the following **driver** sub-directories as follows.

Sub-directory	Driver file
win32	TRI_FX.dll,
emt3000_series	TRI_FX.e30
4. Start EasyBuilderPro and go to the **System Parameters, PLC** tab. The new driver should be listed along with all of the standard drivers. Drivers are listed in alphabetical order.

Refer to the reference documentation provided with the driver. The reference sheet will show communications parameters, cable wiring, Device Types and allowable Device Addresses for creating a project with that driver.